FLOWCHART

Working principles:



iQunet.®

FLOWCHART

Working principles:



After a number of measurement time intervals, the anomaly can be correlated to its position