

INSTALLATION MANUAL


iQunet Base Station Box ACCS 616810-BOX-BS*




***Base Station type IBAS169110-USB-ETH is not included, and has to be ordered separately**



1. **Open the box.**
2. **Install the M16 gland.**
3. **Install the back of the box against the wall, using the 4 corner holes.**
4. **Insert the cable. Insert the micro USB-B connector from the outside to the inside of the box.**



5. **Put the USB cable through the cable tie. Keep an overlength of 200mm.**
6. **Tighten the cable tie.**
7. **Fasten the cable gland.**



8. **Click the iQunet Base Station on the micro USB connector.**
9. **Curl the cable in a wide loop.**



10. Take the cover of the box.



11. Clip the Base Station on the white clips in the cover.



12. Close the box with the 4 corner screws.

DATASHEET BOX

(ACCS-616810-BOX-BS)

Dimensions:	Length	Width	Height
mm:	170	80	85
inch:	6.7	3.1	3.3

Materials:


Material:	Polycarbonate
Base colour:	RAL 7035 -light grey
Cover screws material:	Polyamide
Cover colour:	RAL 7035 -light grey
Cover screws colour:	Grey
Gasket material:	Polyurethane

Temperatures:

Temperature °C (short term):	-40 ... 120 °C
Temperature °C (continuous):	-40 ... 80 °C

Rating:

Ingress Protection (EN 60529): IP66/IP67
Impact Resistance (EN 62262): IK08
Electrical insulation: Totally insulated
Halogen free (DIN/VDE 0472, Part 815): 1
UV resistance: UL 508
Flammability Rating: UL 746C 5"
Glow Wire Test (IEC 695-2-1) °C: 960
NEMA Class: NEMA 1, 4X, 6, 12, 13



DATASHEET EXTENSION CABLE ACCS616010-USB-5MTR

(part of ACCS 616810-BOX-BS)

Replacement type number: iQunet item#: 616010; SKU: ACCS616010-USB-5MTR

Technical specifications:

- **Physical:**
 - **Cable type:** USB Micro B to USB A
 - **Length:** 5 meter
 - **Cable sheath:** PVC
 - **Shielding:** braid shielding
- **Features:**
 - Highly flexible cable
 - High-durability gold plated connectors

